



OWNER'S MANUAL

AIR CONDITIONER



Read this owner's manual thoroughly before operating the appliance and keep it handy for reference at all times.

ENGLISH

TABLE OF CONTENTS

This manual may contain images or content that may be different from the model you purchased.

This manual is subject to revision by the manufacturer.

SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USE	4
Safety Messages.....	4
Notes for Flammable Refrigerant	5
WARNING INSTRUCTIONS	5
Technical Safety.....	5
Installation	6
Operation	8
Wireless Remote Control.....	9
Maintenance	9
Refrigerant	9
CAUTION INSTRUCTIONS	11
Installation	11
Operation	12
Maintenance	12

OPERATION

Before Use	14
Notes for Operation.....	14
Suggestions for Energy Saving.....	14
Product Overview.....	15
1-Way Cassette	15
Display	17
Auto Restart Function.....	18
Wired Remote Control Overview.....	19
Wired Remote Control	19
Operating Mode	21
Cooling, Heating, Dehumidification, Auto, Fan Mode.....	21
Power Mode.....	24
Adjusting the Fan Speed	25
Adjusting the Airflow Direction	25
Changing Temperature in Auto Mode.....	27
Checking Room Temperature.....	28

Additional Function.....	28
Air Purification (On Some Models).....	28
Comfort Cooling (On Some Models).....	29
Child Lock	30
Filter Sign Clear	31
Changing Current Time.....	32
Reservation	32
Simple Reservation	32
Sleep Reservation.....	33
On Reservation	34
Off Reservation.....	35
Holiday Reservation	35
Weekly Reservation.....	36

MAINTENANCE

Cleaning.....	39
Cleaning Interval	39
Cleaning the Air Filter (Matte Type)	40
Cleaning the Air Filter (Glaze Type).....	43
Cleaning the Air Filter (Deluxe Type)	46
Cleaning the PM1.0 Sensor	48
Tips for Maintenance	49
Before Long Periods of Disuse	49
After Long Periods of Disuse	49

TROUBLESHOOTING

Before Calling for Service	50
Operation	50
Performance	53
Calling for Service	54
Situations in which Calling for Service is Necessary.....	54

SAFETY INSTRUCTIONS

READ ALL INSTRUCTIONS BEFORE USE

The following safety guidelines are intended to prevent unforeseen risks or damage from unsafe or incorrect operation of the appliance. The guidelines are separated into 'WARNING' and 'CAUTION' as described below.

Safety Messages



This symbol is displayed to indicate matters and operations that can cause risk.
Read the part with this symbol carefully and follow the instructions in order to avoid risk.



WARNING

This indicates that the failure to follow the instructions can cause serious injury or death.



CAUTION

This indicates that the failure to follow the instructions can cause the minor injury or damage to the product.

Notes for Flammable Refrigerant

The following symbols are displayed on units.



This symbol indicates that this appliance uses a flammable refrigerant. If the refrigerant is leaked and exposed to an external ignition source, there is a risk of fire.



This symbol indicates that the Owner's Manual should be read carefully.



This symbol indicates that service personnel should be handling this equipment with reference to the Installation Manual.



This symbol indicates that information is available in the Owner's Manual or Installation Manual.

WARNING INSTRUCTIONS

WARNING

- To reduce the risk of explosion, fire, death, electric shock, injury or scalding to persons when using this product, follow basic precautions, including the following:

Technical Safety

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person

responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

- Installation or repairs made by unauthorized persons can pose hazards to you and others.
- The information contained in the manual is intended for use by a qualified service technician who is familiar with the safety procedures and equipped with the proper tools and test instruments.
- Failure to read and follow all instructions in this manual can result in equipment malfunction, property damage, personal injury and/or death.
- The refrigerant and insulation blowing gas used in the appliance require special disposal procedures. Consult a service agent or a similarly qualified person before disposing of them.
- When the power cord is to be replaced, the replacement work shall be performed by authorized personnel using only genuine replacement parts.
- If the supply cord is damaged, it must be replaced by the manufacturer or its service agents or a similarly qualified person in order to avoid a hazard.
- The appliance shall be installed in accordance with national wiring regulations.
- This appliance must be properly grounded.
- Do not cut or remove the grounding prong from the power plug.
- Attaching the earth wire to the power outlet cover screw does not ground the appliance unless the cover screw is metal, uninsulated, and the power outlet is grounded through house wiring.
- If you have any doubt whether the air conditioner is properly grounded, have the power outlet and circuit checked by a qualified electrician.

Installation

- Contact an authorized service centre when installing or relocating the air conditioner.

- Contact the dealer, seller, qualified electrician or authorized service centre for cleaning or maintenance the air conditioner.
- Do not install, remove, or re-install the unit by yourself (customer). Installation or repairs done by unauthorized persons can pose hazards to you and others.
- For electrical work, contact the dealer, seller, a qualified electrician or an authorized service centre.
- Do not attempt to do electrical work or grounding work unless you are licensed to do so. Consult with the dealer for electrical work and grounding work.
- Do not install the product on a defective installation stand.
- Be sure the installation area does not deteriorate with age.
- Be sure to only use accessories made by LG which are specifically designed for use with the equipment and have them installed by a professional.
- Never install the outdoor unit on a moving base or a place from where it can fall down.
- Do not install the unit in potentially explosive atmospheres.
- Do not install the air conditioner in a place where flammable liquids or gases such as gasoline, propane or paint thinner are stored.
- Install the panel and the cover of the control box safely.
- Install a dedicated electric outlet and earth leakage breaker before using the appliance.
- Use a standard circuit breaker and fuse that conform to the rating of the air conditioner.
- Do not use a multiple socket, extension power cable or adapter with this appliance.
- The indoor/outdoor wiring connections must be secured tightly, and the cable should be routed properly so that there is no force pulling the cable from the connection terminals. Improper or loose connections can generate heat or cause a fire.
- Do not connect the ground wire to a gas pipe, a lightning rod, or a telephone ground wire.

- Use non-flammable gas (nitrogen) to check for leaks and to purge air; using compressed air or flammable gas may cause fire or explosion.

Operation

- Do not modify or extend the power cable. Scratches or peeling insulation on the power cables may result in fire or electric shock, and the cables should be replaced.
- Make sure that the power cable is neither dirty, loose, nor broken.
- Do not place any objects on the power cable.
- Take care to ensure that the power cable could not be pulled out or damaged during operation.
- Never touch, operate, or repair the air conditioner with wet hands.
- Do not insert hands or other objects through the air inlet or outlet while the air conditioner is operating.
- Make sure that nobody, especially children, climbs on or hits the outdoor unit.
- Be sure to use only those parts listed in the service parts list. Never attempt to modify the equipment.
- Do not touch the refrigerant pipe, water pipe or any internal parts while the unit is operating or immediately after operation.
- Do not leave flammable substances such as gasoline, benzene, or thinner near the air conditioner.
- Do not use the air conditioner for an extended period of time in a small place without proper ventilation.
- Be sure to ventilate sufficiently when the air conditioner and a heating appliance such as a heater are used simultaneously.
 - There is the possibility of oxygen deficiency.
- Do not block the inlet or outlet airflow.
- Cut off the power supply if there is any noise, smell, or smoke coming from the air conditioner.
- Contact an authorized service centre if the air conditioner is submerged by flood waters.

- In the event of a gas leak (such as Freon, propane gas, or LP gas), ventilate sufficiently before using the air conditioner again.
- Stop operation and close the window during a storm or hurricane. If possible, remove the product from the window before the hurricane arrives.

Wireless Remote Control

- Never mix different types of batteries, or old and new batteries in the remote control.
- Do not recharge or disassemble the batteries.
- Dispose of the batteries in a place where there is no danger of fire.
- Stop using the remote control if there is a fluid leak in the battery. If your clothes or skin is exposed to the leaking battery fluid, wash off with clean water.
- If the leaking battery fluid has been swallowed, rinse the inside of the mouth thoroughly and consult a doctor.
- Never let the indoor unit or the remote control get wet.

Maintenance

- Before cleaning or performing maintenance, disconnect the power supply and wait until the fan stops.
 - The fan rotates at a very high speed during operation.
 - There is a possibility of injury if the unit's power is accidentally triggered on while you are cleaning the inner parts of the unit.
- Appliance shall be disconnected from its power source during service and replacing parts.

Refrigerant

General

- Follow the standards of the corresponding region or country for handling the refrigerant and the air conditioner and for disassembling the air conditioner.

- Use only the refrigerant specified on the air conditioner label.
- Do not input air or gas into the system except the specified refrigerant.
- Do not touch the leaking refrigerant during installation or repair.
- If the refrigerant gas leaks during the installation, ventilate the area immediately.
- Be sure to check for refrigerant leaks after installing or repairing the product.
- In the case of refrigerant leakage, consult the dealer. When the air conditioner is to be installed in a small room, it is necessary to take proper measures so that the amount of any leaked refrigerant does not exceed the limiting concentration even when it leaks. If the refrigerant leaks exceeding the level of limiting concentration, an oxygen deficiency accident may happen.

R32 Only



- The appliance shall be stored in a well-ventilated area where the room size corresponds to the room area as specified for operation.
- Ducts connected to an appliance shall not contain an ignition source.
- Any person who is involved with working on or breaking into a refrigerant circuit should hold a current valid certificate from an industry-accredited assessment authority, which authorises their competence to handle refrigerants safely in accordance with an industry recognised assessment specification.
- Servicing shall only be performed as recommended by the equipment manufacturer. Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
- Keep any required ventilation openings clear of obstruction.

- The appliance shall be stored in a room without continuously operating open flames (for example an operating gas appliance) and ignition sources (for example an operating electric heater).
- The appliance shall be stored so as to prevent mechanical damage from occurring.

CAUTION INSTRUCTIONS

CAUTION

- To reduce the risk of minor injury to persons, malfunction, or damage to the product or property when using this product, follow basic precautions, including the following:

Installation

- Use a forklift or 2 or more people to transport the air conditioner.
- Do not install the air conditioner in an area where it is directly exposed to sea wind (salt spray).
- Install the drain hose properly for the smooth drainage of water condensation.
- Install the air conditioner in a place where the noise from the outdoor unit or the exhaust fumes will not inconvenience the neighbours.
- Safely dispose of packing materials such as screws, nails, plastic bags or batteries using proper packaging after installation or repair.
- Exercise caution when unpacking or installing the air conditioner.
- Be especially careful of the case edges and the fins on the condenser and evaporator.
- To avoid vibration or water leakage, keep the product level even when installing it.
- When installing the unit, use the installation kit provided with the product.
- The edges of heat exchanger fins are sharp enough to cut. To avoid injury, wear gloves or cover the fins while working around them.

Operation

- Do not drink the water drained from the air conditioner.
- Do not place objects in direct proximity to the outdoor unit and do not let leaves and other debris accumulate around the unit. Leaves are a hotbed for small animals which can enter the unit. Once inside the unit, such animals can cause malfunctions, smoke or fire if they come into contact with electrical parts.
- Do not let the air conditioner run for a long time when humidity is very high or when a door or a window has been left open.
- Do not expose people, animals, or plants to the cold or hot wind from the air conditioner for extended periods of time.
- Do not use the product for special purposes, such as preserving foods, works of art, etc. The air conditioner is designed for consumer purposes, and is not a precision refrigeration system. There is risk of damage or loss of property.
- Do not turn on the breaker or power when the front panel, cabinet, top cover, or control box cover are removed or opened.
- Do not open the front grille of the product during operation. Do not touch the electrostatic filter, if the unit is so equipped.
- Take care to prevent water from entering the product.
- Make sure that there are no obstacles close to the outdoor unit. The presence of obstacles close to the outdoor unit may reduce the performance of the outdoor unit or increase its operating sound.
- Do not turn off the power immediately after stopping operation. Always wait for at least five minutes before turning off the power.

Maintenance

- Use a sturdy stool or ladder when cleaning, maintaining, or repairing the air conditioner at a height.
- Do not plug or unplug the power supply plug to turn the unit on or off.
- Never use strong cleaning agents or solvents or spray water when cleaning the air conditioner. Use a soft cloth.

- Never touch the metal parts of the air conditioner when removing the air filter.
- Tear apart and throw away plastic packaging bags so that children will not play with them.
- When the product will not be used for a long time, disconnect the power supply plug or turn off the breaker.
- Do not tilt the unit when removing or uninstalling it. The condensed water inside can spill.
- Check the foundation for damage on a regular basis, especially if the product has been in use for a long time.
- Always insert the filter securely. Clean the filter every two weeks or more often if necessary. A dirty filter reduces the efficiency of the air conditioner and could cause product malfunction or damage.

OPERATION

Before Use

Notes for Operation

- Adjust the direction of the airflow vertically or horizontally to circulate indoor air.
- Speed up the fan to cool or warm indoor air quickly, within a short period of time.
- Turn off the appliance and periodically open windows for ventilation. The indoor air quality may deteriorate if the appliance is used for long periods.
- Clean the air filter once every 2 weeks. Dust and impurities collected in the air filter may block the airflow or reduce the appliance performance.


Suggestions for Energy Saving

- Do not over-cool the space. This may be harmful to your health and may consume more electricity.
- Block sunlight with blinds or curtains while you are operating the appliance.
- Keep doors or windows closed tightly while you are operating the appliance.


Product Overview

1-Way Cassette


Matte Type



Glossy Type



Deluxe Type



❶ Air Intake and Air Filter

- Air Intake: Takes in air from the room.
- Air Filter: Reduces dust in the air.

❷ Air Outlet

Circulates air back into the room at the desired temperature.

❸ Operating Status Lamp and Remote Control Receiver


Displays the operating status and contains the receiver for the wireless remote.

❹ Forced Operation Button


Operates the product when the remote control can't be used.

Display


Matte Type



Glossy Type



Deluxe Type



ENGLISH

① Operating Status Lamp

Color	Description
Green	1) Cooling or Heating mode. 2) Hot start or defrost mode before starting heating mode. 3) when reservation is set. 4) Time to clean the filter when the product is operating.
Yellowish Green	Time to clean the filter when the reservation is set.*1
Orange	Time to clean the filter when the product is not operating.

*1 The Clean Filter indicator lamp does not light up in products manufactured after October 2021.

② Forced Operation Button

Operates the appliance when the remote control can't be used.


- Press the ② button for about 2 seconds.

Auto Restart Function


When the appliance is turned on again after a power failure, it resumes operating using the same settings.

- This function is useful in the case of a power failure.
- This function is enabled by the factory default settings.
- If you want to set or disable the auto restart function, press and hold the Forced Operation Button ② for 15 seconds.


Matte Type



Glossy Type




Deluxe Type



Wired Remote Control Overview


Wired Remote Control

You can operate the appliance more conveniently with the wired remote control.



Buttons

Image	Description
	Power  Turns the appliance on/off
	OPER MODE Selects the desired operating mode
	FAN SPEED Adjusts the fan speed
	Temperature Setting   Adjusts the desired temperature

Image	Description
	VENT Operates the appliance and any interlocked ventilation products
	Setting  Sets various functions
	AIR FLOW Selects the direction of airflow
	SUB FUNC Selects sub fuctions
	Reservation  Automatically turns the appliance on or off at a desired time
	Direction  ,  ,  ,  Selects the setting on the display
	OK/CLEAR Sets or cancels settings
	ESC Exits from the menu
❶ Wired Remote Control Receiver Receives a signal form the wireless remote control.	

NOTE

- Some functions may not be available or displayed depending on the product type.
- When using simultaneous operation system, pressing the button on the remote will operate the system after approximately 1-2 minutes.

Operating Mode


Cooling, Heating, Dehumidification, Auto, Fan Mode

Turn on the appliance to control the operating mode.


Cooling Mode

This mode supplies cool air indoors.

- 1 Turn the appliance on by pressing the  button.
- 2 Press the **OPER MODE** button repeatedly to select the Cooling mode.



- You can set the temperature from 16 °C to 30 °C.



NOTE

- You can also set the desired temperature by pressing the  or  button.
- The cooling mode doesn't work if the desired temperature is higher than the room temperature.
 - In this case, lower the desired temperature.
 - For best results, set the desired temperature to about 5 °C lower than the outside temperature.
 - If the desired temperature is higher than the room temperature, the vent will only blow out air rather than cooling.


Heating Mode (On Some Models)

It supplies warm wind to the indoor.


- 1 Turn the appliance on by pressing the  button.

- 3 Press the  or  button to set the desired temperature.
 - Each press increases or decreases the temperature by 1 °C.
 - Some controllers allow you to adjust the temperature by 0.5 °C.

- Press the **OPER MODE** button repeatedly to select the Heating mode.



- Press the **▲** or **▼** button to set the desired temperature.
 - Each press increases or decreases the temperature by 1 °C.
 - Some controllers allow you to adjust the temperature by 0.5 °C.
 - You can set the temperature from 16 °C to 30 °C.




NOTE

- You can also set the desired temperature by pressing the **▲** or **▼** button.
- The heating mode doesn't work if the desired temperature is lower than the room temperature.
 - If so, please increase the desired temperature.
 - For best results, set the desired temperature to about 5 °C higher than the outside temperature.
 - If the desired temperature is lower than the room temperature, the vent will only blow out air rather than heating.

Dehumidification Mode

This function reduces moisture in the air.

- Turn the appliance on by pressing the **⏻** button.
- Press the **OPER MODE** button repeatedly to select the Dehumidification mode.





- 3 Press the **FAN SPEED** button repeatedly to adjust the fan speed.




Auto Mode

This function adjusts the airflow automatically.

- 1 Turn the appliance on by pressing the  button.
- 2 Press the **OPER MODE** button repeatedly to select the Auto mode.



- 3 Press the  or  button to set the desired temperature.
 - Each press increases or decreases the temperature by 1 °C.
 - Some controllers allow you to adjust the temperature by 0.5 °C.
 - You can set the temperature from 16 °C to 30 °C.



NOTE


- You can also set the desired temperature by pressing the  or  button.
- You can use the **FAN SPEED** button during the auto mode.
- You can change other operation mode manually during the Auto mode.

Fan Mode

This function circulates the air without heating or cooling it.

- 1 Turn the appliance on by pressing the  button.

- Press the **OPER MODE** button repeatedly to select the Fan mode.



- Press the **FAN SPEED** button repeatedly to adjust the fan speed.




NOTE

- Ventilation mode does not release cool wind but general fan.
- The Fan mode simply circulates the air within the room without changing its temperature.



Power Mode

You can change the room temperature quickly.


- Turn the appliance on by pressing  button.
- Press the **OPER MODE** button repeatedly to select the cooling mode.



- 3 Press the **FAN SPEED** button repeatedly to select the Power wind.




- Press the **FAN SPEED** button repeatedly to select the desired fan speed.




Cooling, Heating Mode

Each press changes the fan speed in this order:
Slow → Low → Medium → High → Power → Auto



Dehumidification, Auto, Fan Mode

Each press changes the fan speed in this order:
Slow → Low → Medium → High → Auto



NOTE

- Power Mode Setting
 - Temperature(Cooling): 18 °C
 - Fan Speed: Power Wind
 - Wind Direction: Fix to air-cooling position
- Power mode may not be operated depending on the model.


Adjusting the Airflow Direction

You can adjust the direction of the airflow horizontally or vertically.

Adjusting the Fan Speed


You can adjust the fan speed in 5 or 6 steps.

- 1 Press the **AIR FLOW** button repeatedly to select the desired airflow direction.



Icon	Description
	Up-Down & Left-Right Swing Adjusts the up-down and left-right direction of the airflow automatically.
	Left-Right Swing Adjusts the left-right direction of the airflow automatically.
	Up-Down Swing Adjusts the up-down direction of the airflow automatically.
	Indirect Airflow Sets the airflow direction close to the ceiling surface so that the airflow does not blow directly onto the user.
	Direct airflow Sets the airflow direction closer to the floor, directing the airflow toward the user.

- 2 Press the **OK/CLEAR** button to complete the setting.




NOTE


- Some functions may not be operated and displayed depending on the model.

Setting Individual Vane Angle

- 1 Press the button repeatedly to set the individual vane angle.
- The icon below appears on the display screen.




- 2 Press the or button to select the vane.




Icon	Description
1	Select the vane to adjust the wind angle.
STD	Select the vane and fix the wind angle at standard.

- 3 Press the  or  button to select the direction of the vane.



- 4 Press **OK/CLEAR** button to complete the setting.



NOTE

- If the vane is set to **STD**, the direction of all the vanes is fixed like below.





- If there's no button input for 60 seconds, it automatically gets out of setup mode.

- When exiting without pressing **OK/CLEAR** button, the manipulated value is not reflected.
- This function may not be operated and displayed depending on the model.

Changing Temperature in Auto Mode


It setup air-cooling and heating automatically changeable according to the temperature at auto mode.

- 1 Turn the appliance on by pressing  button.
- 2 Press the  button repeatedly until the below icon flashes on the screen.




- 3 Press the  or  button to set the desired value.

- The value can be adjusted 1 to 7.



- After 5 seconds, it turns to display the desired temperature.




Types of Displayed Temperature

Displayed Temperature	Display	Description
Room Temperature		Indicates the current room temperature.
Setting Temperature		Indicates the temperature that is set by user.

NOTE

- Display temperature can be different from actual room temperature if the remote controller is installed at the place where sun-rays are falling directly or the place nearby heat source.

4 Press **ESC** button to complete the setting.



NOTE

- If no buttons are pressed for about 25 seconds, it automatically gets out of setup mode.

Checking Room Temperature

It checks the current room temperature.



- Press the button. The current room temperature is briefly displayed on the remote control screen for 5 seconds.

Additional Function


Air Purification (On Some Models)

Even fine dust that cannot be filtered by the basic pre-filter is eliminated.

- 1 Press the **SUB FUNC** button repeatedly to display the  icon on the screen.



- 2 Press **OK/CLEAR** button to complete the setting.





- If you want independent air purification function, please setup air purification by pressing additional operation button at ventilation mode.
- To escape from the setting mode during setup, press the **ESC** button.

Comfort Cooling (On Some Models)

You can automatically control the cooling strength to maintain a pleasant feeling without turning off the appliance.

- It is operated after the indoor temperature reached the desired temperature.


- 1 Press the **SUB FUNC** button repeatedly to display the  icon on the screen.



NOTE

- If no buttons are pressed for about 25 seconds, it automatically gets out of setup mode.
- When exiting without pressing **OK/CLEAR** button, the manipulated value is not reflected.
- Air purification function is possible only when product is operating.

- 2 Press **OK/CLEAR** button to complete the setting.



NOTE

- If the same procedure is conducted, the  icon is disappeared on the screen.
- If no buttons are pressed for about 25 seconds, it automatically gets out of setup mode.
- When exiting without pressing **OK/CLEAR** button, the manipulated value is not reflected.
- To escape from the setting mode during setup, press the **ESC** button.



Child Lock

You can prevent children or others from carelessly using the appliance by disabling the buttons.


- 1 Press the  button repeatedly until the  icon is flashing on the screen.

- : Lock


- : Unlock



- 2 Press the  or  button to select lock setting.



- 3 Press **OK/CLEAR** button to complete the setting.





NOTE

- If no buttons are pressed for about 25 seconds, it automatically gets out of setup mode.
- When exiting without pressing **OK/CLEAR** button, the manipulated value is not reflected.
- To escape from the setting mode during setup, press the **ESC** button.


Filter Sign Clear

You can clear the filter cleaning indicator when that is displayed on the screen.

- 1 Press the  button repeatedly until the  icon is flashing on the screen.



- 2 Press **OK/CLEAR** button to complete the setting.



NOTE

- If the filter is covered by dust, it will reduce cooling or heating efficiency and accumulate more electric power.
- Therefore, clean the filter whenever cleaning time is expired.

NOTE

- Filter cleaning indication is automatically cancelled without separate cancellation after certain period of time.
- To escape from the setting mode during setup, press the **ESC** button.

Changing Current Time

- 1 Press the  button repeatedly to have the current time flashes on the screen.



- 2 Press the  or  button to select desired day.



- 3 Press the  button to move to AM/PM setting.

- 4 Press the  button to select AM/PM.



NOTE

- Press the  button, if you want to go back to day setting.

- 5 Press the  button to move to hour setting.

- 6 Press the ,  button to select the desired hour.



NOTE

- Press the  button, if you want to go back to AM/PM setting.

- 7 Press the  button to move to minute setting.

- 8 Press the ,  button to select the desired minute.



- 9 Press **OK/CLEAR** button to complete the setting.

NOTE

- In case of exit with incomplete information, it will return to the previous setting.
- When exiting without pressing **OK/CLEAR** button, the manipulated value is not reflected.
- To escape from the setting mode during setup, press the **ESC** button.

Reservation


Simple Reservation

You can set the appliance to turn on or off automatically at a desired time.


Setting the On Reservation

This function can be set when the appliance is turned off.

- 1 Press the  button repeatedly until the **SIMPLE** appears on the display screen.



- 2 Press the  or  button to set the desired hour.
- Hour can be set from 1 hour to 7 hours in the unit of 1 hour .




- 3 Press the **OK/CLEAR** button to complete the setting.

Setting the Off Reservation


This function can be set when the appliance is turned on.

- 1 Press the  button repeatedly until **SIMPLE** appears on the display screen.



- 2 Press the  or  button to set the desired hours.

- Hours can be set in the units of 1 hour from 1 hour to 7 hours.



- 3 Press the **OK/CLEAR** button to complete the setting.

NOTE

- If no buttons are pressed for about 25 seconds, the display automatically exits the setup mode.
- If the display exits the setup mode before the **OK/CLEAR** button is pressed, the value is not set.
- To escape from the setting mode during setup, press the **ESC** button.

Sleep Reservation

You can set the appliance to turn off automatically after a set time. The appliance will automatically change the temperature and fan speed.

This function can be set when the appliance is turned on.

CAUTION

- Use the proper settings for sleeping.
 - Setting the temperature too low is not good for your health.

- 1 Press the  button repeatedly until **SLEEP** appears on the display screen.



- 2 Press the  or  button to set the desired time.
 - The time can be set up to 7 hours.



- 3 Press the **OK/CLEAR** button to complete the setting.

NOTE

- Sleep mode automatically adjusts the desired temperature for a comfortable sleep.
 - This could result in a different desired temperature being displayed on the remote and the air conditioner.
- Sleep reservation operates as off reservation for the product whose temperature adjustment isn't controlled by unit of 0.5 °C.
- If no buttons are pushed for 60 seconds, the display automatically exits the setup mode.
- If you exit without pressing the **OK/CLEAR** button, the settings are not saved.
 - If the reservation is set, **SLEEP** is displayed on the lower part of the LCD screen.
- If the air conditioner is connected to a ventilation product, it will enter the sleep mode after the set time has elapsed.
- To escape from the setting mode during setup, press the **ESC** button.

On Reservation

You can set the appliance to turn on automatically at a desired time.

- 1 Press the  button repeatedly until **ON** appears on the display screen.



- 2 Press the  or  button to set **AM/PM**.



- 3 Press the  button to move to the hour setting.

- 4 Press the  or  button to set the desired hour.



- 5 Press the  button to move to the minute setting.

- 6 Press the  or  button to set the desired minutes.



- 7 Press the **OK/CLEAR** button to complete the setting.

NOTE

- If no buttons are pressed for about 25 seconds, the display automatically exits the setup mode.
- If you exit without pressing the **OK/CLEAR** button, the settings are not saved.

- If the reservation is set, **RESERVATION - ON** appears in the lower section of the LCD screen and the appliance runs at the set time.
- If the schedule is canceled, **RESERVATION - OFF** disappears from the display.
- To escape from the setting mode during setup, press the **ESC** button.

- 7** Press the **OK/CLEAR** button to complete the setting.

NOTE

- If no buttons are pressed for about 25 seconds, the display automatically exits the setup mode.
- If the display exits before the **OK/CLEAR** button is pressed, the settings are not saved.
 - If the schedule is set, **RESERVATION - OFF** appears in the lower section of the LCD display and the appliance turns off at the set time.
 - If the schedule is canceled, **RESERVATION - OFF** disappears from the display.
- To escape from the setting mode during setup, press the **ESC** button.

Off Reservation

You can set the appliance to turn off automatically at a desired time.

- 1** Press the  button repeatedly until **OFF** appears on the display screen.



- 2** Press the  or  button to set **AM/PM**.



- 3** Press the  button to move to the hour setting.

- 4** Press the  or  button to set the desired hour.



- 5** Press the  button to move to the minute setting.

- 6** Press the  or  button to set the desired minutes.



Holiday Reservation

You can automatically stop the appliance on a reserved day that you set.

- 1** Press the  button repeatedly until **HOLIDAY** appears on the display screen.



- 2** Press the  button to move to the day setting.



- 3** Press the  or  button or the **OK/CLEAR** button to set the desired day.



- 4** Press the  button if you want to include more days in reservation.

5 Press the or button or the **OK/CLEAR** button again to set the desired days.



6 Press the **ESC** button to complete the setting.

NOTE

- On the set days, the appliance automatically does not run.
- If you turn the appliance on during the scheduled holiday, it automatically stops within 1 hour unless the holiday schedule is canceled.

For example, when you setup monday and thursday to holiday, **MON** and **THU** letters disappears, display is set shown below.



- To escape from the setting mode during setup, press the **ESC** button.

Weekly Reservation

You can automatically turn the appliance on or off on selected days each week.

Weekly reservation can be set by this procedure:

1 Setting Turning On Reservation Day and Time

2 Setting Turning Off Reservation Day and Time


Setting Turning On Reservation Day and Time

1 Press the button repeatedly until **WEEKLY** appears on the display screen.



2 Press the button to move to reservation slot setting.

3 Press the or button to select the desired reservation slot.




4 Press the button to move to the day setting.

5 Press the or button to set the desired day.



6 Press the button to set **AM/PM**.



NOTE

- Press the button, if you want to go back to the day setting.

7 Press the button to move to the hour setting.

- 8 Press the or button to set the desired hour.

- The hour can be set from 0 to 12.



NOTE

- Press the button, if you want to go back to the AM/PM setting.

- 3 Press the or button to set the desired hour.

- The hour can be set from 0 to 12.



NOTE

- Press the button, if you want to go back to the AM/PM setting.

- 9 Press the button to move to the minute setting.

- 10 Press the or button to set the desired minute.

- The minute can be set from 00 to 59.



- 4 Press the button to move to the minute setting.

- 5 Press the or button to set the desired minute.

- The minute can be set from 00 to 59.



- 11 Press the button to set off reservation day and time.

Setting Turning Off Reservation Day and Time

- 1 Press the button to set **AM/PM**.



- 2 Press the button to move to the hour setting.

- 6 Press the **OK/CLEAR** button to complete the setting.

NOTE

- Once the weekly schedule is set up, it continues to operate until you cancel it.
- If the turn on time and turn off time are set to the same time, the weekly schedule will not run.
- The appliance turns on to the desired temperature if it is set up during the scheduling process.
 - If the desired temperature is not set, the appliance is turned on automatically with the desired temperature of the previous operation.
- The display shows a bar ① under the day(s) that have a weekly schedule attached.




NOTE

- To escape from the setting mode during setup, press the **ESC** button.
-

MAINTENANCE

Cleaning

Cleaning Interval



- If the filter is clogged with dust, the cooling/heating efficiency will drop.
 - 6 % of the electricity will be wasted.
- The feature may vary depending on the model type.

Filter Type	Water Washing	Interval
❶ Air Filter	O	2 Weeks
❷ PM1.0 Filter ^{*1}	O	6 Months
❸ Deodorization Filter ^{*1}	X	6 Months

^{*1} This filter is provided only when the air purifying front panel is installed.

NOTE

- Never use water that is hotter than 40 °C when you clean the filters. Doing so may cause deformation or discolouration.
- Never use volatile substances when you clean the filters. Doing so may damage the surface of the appliance.

Cleaning the Air Filter (Matte Type)

⚠ WARNING

- Wear gloves during the work.
- Before cleaning or performing maintenance, disconnect the power supply and wait until the fan stops.



⚠ CAUTION

- When you remove the air filter, do not touch the metal parts of the indoor unit. Doing so may cause an injury.
- Do not bend the air filter, as it may break.
- Assemble the air filter properly to prevent dust and other substances from entering the product.



Removing the Filter

1 Press the knobs and open the front grille.



- The arrows are marked near the knobs.





2 Press the clips on the air filter and pull it down.



3 Pull the air filter forward to remove it.




4 Press the knobs on the PM1.0 filter to remove it.



⚠ WARNING


- Don't touch the PM1.0 Filter within 10 seconds after opening the front grille.
- It may cause an electric shock.

- 5** After pushing down the ring, remove the deodorization filter.




Cleaning the Air Filter

- 1** Clean the air filter with a vacuum cleaner or wash it with lukewarm water and a mild detergent.



- 2** Dry the filter in the shade.



Cleaning the PM1.0 Filter and Deodorization Filter

PM1.0 Filter

- 1** Soak the PM1.0 filter in enough water to submerge it and shake it several times to clean it.
- Clean the filter without disassembling it.
 - If the filter is heavily soiled, soak it in lukewarm water with neutral detergent for 30 minutes, then rinse thoroughly with clean water.



- 2** Dry in the shade for about a day.
- If you assemble the PM1.0 filter with moisture remaining, 7 beeps will sound.

⚠ CAUTION

- Do not use hot water over 40 °C or volatile liquids.
- Do not use acidic detergents such as citric acid.
- Drying with a hot air heater, such as a hair dryer or a heater, could damage or deform the filter.
- The inside of the filter is sharp, so do not rub or touch it directly.

Deodorization Filter



Do not wash the deodorization filter with water and dry for about 3 hours under weak sunlight or fluorescent light.

- Washing the filter with water could damage or deform it.





Mounting the Filter



- 1** After pushing down the ring, insert the deodorization filter.




- 2** Insert the PM1.0 filter.



- 3** Insert the air filter.



- 4** Close up the front grille and secure it by pushing the points near the knobs.



Cleaning the Air Filter (Glaze Type)

⚠ WARNING


- Before cleaning or performing maintenance, disconnect the power supply and wait until the fan stops.
- When you remove the air filter, do not touch the metal parts of the indoor unit. Doing so may cause an injury.

NOTE


- Do not bend the air filter, as it may break.
- Assemble the air filter properly to prevent dust and other substances from entering the product.

Removing the Filter


- 1 Press the Knobs ① on both sides and open the air intake.




- 2 Press the Clips ② on both sides and remove the air filter.



- 3 Press the Clip ③ on both sides and detach the PM1.0 filter.




- 4 Pull the knob ④ down and remove the deodorization filter ⑤.




Cleaning the Air Filter

- 1 Clean the air filter with a vacuum cleaner or wash it with lukewarm water and a mild detergent.



- 2 Dry the filter in the shade.




Cleaning the PM1.0 Filter and Deodorization Filter

PM1.0 Filter

- 1) Soak the PM1.0 filter in enough water to submerge it and shake it several times to clean it.
 - Clean the filter without disassembling it.

- If it is heavily soiled, soak it in lukewarm water with neutral detergent for 30 minutes, then rinse thoroughly with clean water.



- 2) Dry in the shade for about a day.
 - If you assemble the PM1.0 filter with moisture remaining, 7 beeps will sound.


⚠ CAUTION

- Do not use hot water over 40 °C or volatile liquids.
- Do not use acidic detergents such as citric acid.
- Drying with a hot air heater, such as a hair dryer or a heater, could damage or deform the filter.
- The inside of the filter is sharp, so do not rub or touch it directly.

Deodorization Filter


Do not wash the deodorization filter with water and dry for about 3 hours under weak sunlight or fluorescent light.

- Washing the filter with water could damage or deform it.




Mounting the Filter


- 1 Pull the knob ⑥ down and insert the deodorization filter ⑦.




- 2 Insert PM1.0 filter.



- 3 Insert the air filter.



- 4 Close the air intake and fix the air intake by pressing left, right and centre.



Cleaning the Air Filter (Deluxe Type)

⚠ WARNING

- Wear gloves during the work.
- Before cleaning or performing maintenance, disconnect the power supply and wait until the fan stops.


⚠ CAUTION

- When you remove the air filter, do not touch the metal parts of the indoor unit. Doing so may cause an injury.
- Do not bend the air filter, as it may break.
- Assemble the air filter properly to prevent dust and other substances from entering the product.


Removing the Filter

1 Press the knobs and open the front grille ①.


- The arrows are marked on the knobs.



2 Press the clips on the air filter ② and pull it down.




3 Pull the air filter forward to remove it.




Cleaning the Air Filter

1 Clean the air filter with a vacuum cleaner or wash it with lukewarm water and a mild detergent.





- 2 Dry the filter in the shade.




Mounting the Filter

- 1 Insert the air filter.



- 2 Close up the front grille and secure it by pushing the knobs.



Cleaning the PM1.0 Sensor


NOTE

- This process is applicable only when the PM1.0 sensor is installed.


⚠ WARNING

- Turn off the power to the appliance before work.
- Disconnect the power supply to the appliance before work.
- When cleaning the sensor, be careful so as to avoid falling accidents.
- When removing the sensor corner cover, be careful not to drop the product.


- 1** Put your finger in the indicator.




- 2** Open the front grille and pull down the PM1.0 sensor case.



- 3** Lower the PM1.0 sensor case all the way down and rotate the dust sensor case to fix it.




- 4** Open the PM1.0 sensor cover on the side of the case.



- 5** Wipe off any dust adhering to the lens using a cotton swab slightly moistened with water.

Then wipe again with a dry cotton swab to remove moisture.



- 6 Close the PM1.0 sensor case, then install the PM1.0 sensor case in its original position.

NOTE

- It is recommended to clean the PM1.0 sensor every 6 months.(assuming 8 hours of daily use)
- PM1.0 Sensor is only included with air purification panel.
- The features can be different depending on the model.

After Long Periods of Disuse

- 1 Clean the air filter and install it in the indoor unit.
- 2 Check that the air inlet and outlet of the indoor/outdoor unit are not blocked.
- 3 Check that the ground wire is connected correctly.
 - The ground wire may be connected to the side of the indoor unit.

Tips for Maintenance

Before Long Periods of Disuse

- 1 Operate the air conditioner in the **Fan mode** for 2 to 3 hours.
 - This will dry out the internal mechanisms.
- 2 Turn off the appliance.
- 3 Turn off the breaker.

TROUBLESHOOTING

Before Calling for Service

Please check the following before you contact the service centre. If the problem persists, contact your local service centre.

NOTE

- Some functions may not be supported, depending on the model.

Operation

Symptoms	Possible Cause & Solution
The appliance does not work normally.	Burning smell and strange sounds are coming from the appliance. Turn off the appliance, switch off or disconnect the power supply, and contact a service centre.
	Water leaks from the indoor unit even when the humidity level is low. Turn off the appliance, switch off or disconnect the power supply, and contact a service centre.
	The power cable is damaged or it is generating excessive heat. Turn off the appliance, switch off or disconnect the power supply, and contact a service centre.
	A switch, a circuit breaker (safety, ground) or a fuse is not operating properly. Has the fuse blown or has the circuit breaker been tripped? Turn off the appliance, switch off or disconnect the power supply, and contact a service centre.
	The appliance generates an error code from its self-diagnosis. Turn off the appliance, switch off or disconnect the power supply, and contact a service centre.
The fan speed cannot be adjusted.	The Jet mode or Auto Operation mode is selected. In some operating modes, you cannot adjust the fan speed. Select an operating mode in which you can adjust the fan speed.
	The airflow generated by the air conditioner may be automatically adjusted during operation. When the air conditioner reaches the set temperature, it reduces the airflow rate to avoid generating cool airflow when heating, or to minimize energy consumption and indoor humidity change when cooling.
The temperature cannot be adjusted.	The Fan mode or Jet mode is selected. In some operating modes, you cannot adjust the temperature. Select an operating mode in which you can adjust the temperature.

Symptoms	Possible Cause & Solution
The appliance stops during operation.	The appliance is suddenly turned off. The Off Timer function may have timed out, which turns the appliance off. Check the timer settings.
	Have you made a mistake in timer operation? Set the timer correctly.
	A power failure has occurred during operation. Wait for the power to come back on. If you have the Auto Restart function enabled, your appliance will resume its last operation several minutes after power is restored.
The appliance does not work.	A fuse blew or the power supply is blocked. Replace the fuse or check if the circuit breaker has tripped.
	The appliance is unplugged. Check whether the power cord is plugged into the outlet or the power isolators are switched on.
	A power failure has occurred. - Turn off the appliance when a power failure occurs. - When the power is restored, wait 3 minutes, and then turn on the appliance.
	The voltage is too high or too low. Check if the circuit breaker has tripped.
	The appliance was turned off automatically at a preset time. Turn the appliance on.
	The battery orientation in the wireless remote control is incorrect. - Make sure that the batteries are inserted correctly in your wireless remote control. - If the batteries are placed correctly, but the appliance still does not operate, replace the batteries and try again.
	Are the indoor unit's air inlet or outlet vents obstructed? Remove the obstacles.
The appliance does not emit cool air.	Air is not circulating properly. Make sure that there are no curtains, blinds, or pieces of furniture blocking the front of the appliance.
	The air filter is dirty. - Clean the air filter once every 2 weeks. - See "Cleaning the Air Filter" for more information.

Symptoms	Possible Cause & Solution
The appliance does not emit cool air.	The room temperature is too high. In summer, cooling the indoor air fully may take some time. In this case, select the Jet mode to cool the indoor air quickly.
	The room may have been very hot when the room air conditioner was first turned on. Allow time for it to cool down.
	Cold air is escaping from the room. Make sure that no cold air is escaping through the ventilation points in the room.
	The desired temperature is higher than the current temperature. Set the desired temperature to a level lower than the current temperature.
	There is a heating source nearby. Avoid using heat generators like electric ovens or gas burners while the air conditioner is in operation.
	Fan mode is selected. - During Fan mode, air blows from the appliance without cooling or heating the indoor air. - Switch the operating mode to a cooling operation.
	Outside temperature is too high. The cooling effect may not be sufficient.
The appliance does not emit warm air.	When the Heating mode starts, the vane is almost closed, and no air comes out, even though the outdoor unit is operating. This is normal. Please wait until the appliance has generated enough warm air to blow through the indoor unit.
	The outdoor unit is in Defrosting mode. In Heating mode, ice and frost is built up on the coils when the outside temperature falls. The Defrosting mode reduces a layer of frost on the coil, and it should finish in approximately 15 minutes.
	Outside temperature is too low. The heating effect may not be sufficient.
The air conditioner changes generated airflow during operation.	When the appliance reaches the desired temperature, the airflow rate reduces in order to avoid generating cool airflow during heating, or to minimize energy consumption and indoor humidity change during cooling. This symptom is normal.
It seems that condensation is leaking from the air conditioner.	Condensation occurs when the airflow from the air conditioner cools the warm room air. This symptom is normal.

Performance

Symptoms	Possible Cause & Solution
The indoor unit is still operating even when the appliance has been turned off.	The Auto Clean function is being operated. Allow the Auto Clean function to continue since it reduces any remaining moisture inside the indoor unit. If you do not want this function, you can turn the indoor unit off.
The air outlet on the indoor unit is discharging mist.	The cooled air from the appliance makes mist. When the room temperature decreases, this phenomenon will disappear.
Water leaks from the outdoor unit.	In the heating operations, condensed water drops from the heat exchanger. Install a drain hose under the base pan. Contact the installer.
There is noise or vibration.	A clicking sound can be heard when the appliance starts or stops due to movement of the reversing valve. Creaking sound: The plastic parts of the indoor unit creak when they shrink or expand due to sudden temperature changes. Noise is normal during or after operation. It is not a sign of malfunction.
	Flowing sound: This is the flow of refrigerant through the appliance. Blowing sound: This sound generates when compressed air is released into the atmosphere. This is the sound of the dehumidifying water being processed inside the air conditioning unit. These are normal symptoms. The noise will stop.
Crack sound is heard.	This sound is generated by the expansion or constriction of the front panel, etc. due to changes of temperature. These are normal symptoms. The noise will stop.
The indoor unit gives off an odour.	Odours (such as cigarette smoke) may be absorbed into the indoor unit and discharged with airflow. If the smell does not disappear, you need to wash the filter. If this does not work, contact the service centre to clean your heat exchanger.
	Check that this is not a damp smell exuded by the walls, carpet, furniture or cloth items in the room. If the smell comes out from walls, carpet, furniture or cloth item, clean it.
Remote control display is faint, or no display at all.	Are the batteries depleted? Replace the batteries with a new one.
	Are the batteries inserted in the opposite + and - directions? Make sure that the + and - terminals of the batteries are oriented correctly.

Calling for Service

Situations in which Calling for Service is Necessary

If the appliance is in one of the following situations, please call the service.

- Anything abnormal, such as a burning smell, loud noises, etc., occur;
 - Turn off the appliance and circuit breaker.
 - Never try to repair or restart the appliance yourself.
- Main power cord is too hot or damaged.
- Error code is generated by self diagnosis.
- Water leaks from the appliance even if the humidity is low.
- Any switch, circuit breaker(safety, earth) or fuse fails to work properly.

NOTE

- The user is responsible for routine checks and cleaning to avoid poor appliance performance.
 - In cases involving unusual or special situations and circumstances servicing must be carried out only by trained service personnel.
-



Manufacturer :

LG Electronics Inc.

84, Wanam-ro, Seongsan-gu, Changwon-si, Gyeongsangnam-do, KOREA

UK Importer: LG Electronics U.K. Ltd

Velocity 2, Brooklands Drive, Weybridge, KT13 0SL

Eco design requirement

- The information for Eco design is available on the following free access website.
<https://www.lg.com/global/support/cedoc/cedoc>